




- | | |
|---------|---|
| 1 | Outdoor air |
| 2 | Supply air |
| 3 | Extract air |
| 4 | Exhaust air |
| SAF | Supply fan |
| EAF | Extract fan |
| FILTER | Extract/Supply filter |
| RHS/EAT | Relative humidity sensor / Extract air temperature sensor |
| RHE | Rotating heat exchanger |
| SAT | Supply air temperature sensor |
| OAT | Outdoor air temperature sensor |
| ELH | Electric heater |
| OHT | Overheat temperature sensor |
| EMT | Emergency thermostat |